

Contec® CritiGear™ HD Chemo Gown

**USP <800> compliant gown for use
when compounding hazardous drugs***

Contec® CritiGear™ HD Chemo Gowns are designed to offer broad protection against a wide range of hazardous drug compounds, in compliance with ASTM F3267-22 standards. These gowns not only safeguard the wearer but also provide comfort. The disposable gown features generous sleeve lengths with knit cuffs and thumb loops, ensuring a secure fit and comfort during compounding activities.

Our CritiGear HD Chemo Gowns are constructed with sealed seams, meeting USP <800> requirements, and are reinforced with highly visible blue tape to easily identify the correct gown for the appropriate application. The wrap-around design, with hook-and-latch closures at the back, ensures full coverage during compounding tasks. Additionally, the extra-long ties allow the gown to be securely tied to the side, keeping it out of the way during critical activities. Combined with multiple size options, these features ensure a comfortable and secure fit for users.



Contec CritiGear HD Chemo Gowns feature fabric that is proven to provide the wearer broad protection from a wide range of hazardous drugs*.

Features	Benefits
Polypropylene construction	<ul style="list-style-type: none">• Low-lint, latex free disposable fabric is compliant with the 2023 revision to USP Chapter <797>
Broad Protection Coverage	<ul style="list-style-type: none">• *Specifically tested against <i>Cisplatin, Cyclophosphamide, Doxorubicin, Etoposide, Fluorouracil, Paclitaxel, and Thiotepa</i> per ASTM F3267-22
USP <800> compliant	<ul style="list-style-type: none">• Constructed according to USP <800> requirements for hazardous drug compounding
Complete protection	<ul style="list-style-type: none">• Full closure back, hook and loop neck closure, and taped seams provide total coverage against permeation
Thumb loop	<ul style="list-style-type: none">• Knitted cuffs with thumb loops eliminates movement of sleeves
Easy removal design	<ul style="list-style-type: none">• Hook and loop closure allows user to simply untie side tie and pull gown down and away from the body with one hand
Combination sizing	<ul style="list-style-type: none">• Combination sizing for ease of donning over other protective frocks such as Contec CritiGear Cleanroom Frocks

Part no.	Description	Size	Packaging
HCGA0800-S/M	Contec CritiGear HD Chemo Gown	Small/Medium	10/bag, 3 bags/case
HCGA0800-L/XL	Contec CritiGear HD Chemo Gown	Large/X-Large	10/bag, 3 bags/case
HCGA0800-2XL/3XL	Contec CritiGear HD Chemo Gown	2X-Large/3X-Large	10/bag, 3 bags/case
HCGA0800-4XL/5XL	Contec CritiGear HD Chemo Gown	4X-Large/5X-Large	10/bag, 3 bags/case
HCGA0800-6XL/7XL	Contec CritiGear HD Chemo Gown	6X-Large/7X-Large	10/bag, 3 bags/case