



# EasyCurve™ Mopping System

Curved foam mop for cleaning floors, walls, and ceilings

## Description

Designed especially for controlled environments, the EasyCurve mop consists of a flat, polyester fabric-laminated foam mop head attached to a curved, stainless steel frame to provide superior performance and ease of use compared to other all-surface cleaning systems. The highly absorbent and drip-free mop head securely attaches to the curved frame by a unique system of latching tabs, but remains simple and easy to remove.

Lightweight and maneuverable, this mopping system reduces operator fatigue and ensures proper "place and pull" technique. Compatible with most common solutions and solvents.

The microfiber face provides superior pickup and mop dry.

Durable and simple with no moving parts. All components are autoclavable, and sterile mop heads are available.

## Technical Data

Mop head component materials (cleaning surface first)	Knitted polyester fabric / hydrophilic urethane foam / .014" rigid polyester film
Construction	Multi-layer; flame bonded / inert, hi-temp adhesive
Chemical compatibility	Recommended for continuous use in most common disinfectant solutions, when mixed according to manufacturers' directions. Recommended limited use up to one hour in "bleach" solutions over 40,000ppm hypochlorite. Not compatible with acetone and other ketones

Attribute; (units)	Value **	Test Method
Mop weight, dry; (g/mop)	52	CTM 004-03
Sorbency in water		CTM 004-03
Capacity; (mL/mop)	617	
Rate; (sec.)	<1	
Non-volatile residue, NVR		CTM 005-01
In deionized water; (g/mop)	ND	
In isopropanol; (g/mop)	0.020	
Particles ≥ 0.5µm; (x10 <sup>6</sup> /mop)	0.22	CTM 006-01
Fibers > 100µm; (x10 <sup>3</sup> /mop)	0.05	CTM 006-01

\*\* ND = None detected; levels are below detection limit of test equipment

Part Number	Description	EA/OB1	OB1/OB2	OB2/CS	EA/CS
EZMP0300	EasyCurve Ribbed Microfiber mop head, 14" x 4.25" x 0.75" (36 x 11 x 2cm)	4	1	12	48

Part Number	Description	EA/OB1	OB1/OB2	OB2/OB3	OB3/CS	EA/CS
EZMP0350	EasyCurve Ribbed Microfiber mop head, 14" x 4.25" x 0.75" (36 x 11 x 2cm), sterile	1	4	1	12	48

Key: EA = Each, OB1 = Outer Bag 1, OB2 = Outer Bag 2, OB3 = Outer Bag 3, CS = Case

### Notes:

- 1) The information presented here is applicable to the part numbers shown above, as well as to any product containing the same materials and produced under the same conditions, regardless of product size or packaging configuration. Please contact a Contec sales representative for more details.
- 2) Data shown are typical values and should not be used as product specifications.
- 3) Valid product comparisons may only be obtained through side-by-side testing in the same test facility, under similar conditions.
- 4) Current and/or comparison data may be available. Please contact a Contec sales representative for details.

Revision date: 10/25/16



Copyright © 2016 Contec, Inc. All rights reserved.

**North America**  
P.O. Box 530  
Spartanburg, SC 29304 USA  
Phone: +1-864-503-8333  
www.contecinc.com

**Europe**  
Zl du Prat – RP 3707  
56037 VANNES Cedex  
FRANCE  
+33 297 437 698

**China**  
No.17 Longyun Road  
Suzhou 215024  
CHINA  
+ 86-512-6274 4050